


Thank you for choosing
Phomemo


Product Description




Power indicator status

Indicator light color		Status	Solution
Power light	Orange light flash slowly	1. No printer ribbon 2. Press the cutting button when the printer is printing 3. Battery is lower than 10%	1. Press the cutting button again to cut the ribbon and print text again 2. Please use the cutting button to cut the printer ribbon and print again 3. Please connect the power source
	Orange light flash quickly	Power is lower than 5%, so can't print.	Connect to power sauce
	Orange light smooth dimming from 0%-100%	Charing,power was lower than 60%	/
	Blue light smooth dimming from 0%-100%	Charing,power was higher than 60%	/
	Blue light always on	Full charge	/
Bluetooth light	Blue light on	USB or Bluetooth connected	/
	Blue light flash slowly	USB or Bluetooth not connected	Please connect usb or bluetooth

Operation Guidance



1. Fully charge the battery before using the first time. To turn on the machine, press and hold the power button for 3 seconds




2. To turn on bluetooth, search for the device on the app and select device


Search for Phomemo
and download the app



Switch print ribbon



1. Open the side cover outwards in the direction of the arrow (see above)



2. Insert the label tape cassette correctly as shown in the picture above.
Close the cover to complete the installation.

Attention

- ① Insert or pull out the charge cable gently to avoid any damages to the port.
- ② Pull out the cable after charging is complete.
- ③ Do not charge or use the printer in high temperature, high humidity, or foggy circumstances (e.g. in a bathroom, a steam room or beside a fire) which may be dangerous. (NOTE: This machine is not suitable for tropical environments)
- ④ Improper charging methods may cause damage.
- ⑤ Do not touch the print head; it may hot.
- ⑥ Be aware of the sharp blade.
- ⑦ If the machine is malfunctioning,
the reset hole can be used to restart the machine.

Note:

This equipment has been tested and found to comply within the limits of a Class B digital device, pursuant to Part 1 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/T technician for help.

Battery Warning Description

Never disassemble, strike, squeeze or put into fire;

If there is severe swelling, do not continue to use;

Do not put in a high temperature environment. Do not use if immersed in water;

Be sure to replace with an appropriate type of battery. (There is danger of explosion if you replace it with the wrong type of battery.)

Be sure to dispose of the used battery as instructed.

FCC Caution

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Product Warranty Description

Thank you for choosing Phomemo.

1. The free warranty period is 1 year from the date of purchase.
2. Within 30 days from the date of receipt, the user can choose to return the item.

Please save the warranty/maintenance card properly. The warranty/maintenance card will not be replaced if lost or damaged.

Non-warranty regulations

The warranty is void under the following conditions:

- ① Exceeding the warranty period.
- ② Not presenting the original warranty/maintenance card.
- ③ Presenting a damaged warranty/maintenance card (e.g. torn or tampered with) Altering product information.
- ④ Damage caused by unauthorized repair, disassembling, etc.
- ⑤ Damage caused by human error.
- ⑥ Damage caused by natural disasters such as earthquakes, floods, windstorms, lightning strikes, or external disasters such as fires and home collapses.
- ⑦ Failure or damage caused by harsh conditions (oil, dust, moisture, direct sunlight, etc.) or failure to use or care for as required by the instruction manual.

Warranty/Maintenance Card

☐

Replace

☐

Return

☐

Repair

User Info	Name:	Gender:	Phone:
	Address:		
Product information	Date of purchase:		
	Product Order Number:		
	Product Serial Number:		
Return , Replace, or Repair Request	Reasons:		
Maintenance records	Fault conditions:		Maintenance staff:
	Processing situation:		Repair date:
	Repair ticket number:		Date of inspection: